TECHNICAL NOTE

pH Analysis Workflow with Low-Maintenance pH/ATC Electrode General Operating Procedure Recommendations

Expedite your SOP development by leveraging these general operating procedure recommendations for equipment setup, pH calibration, and pH measurements. In this technical note, a pH/ATC gel-filled electrode is employed, offering the advantages of a low-maintenance electrode that does not require electrode fill solution and a built-in temperature sensor for more reproducible pH measurements.

Recommended Equipment

- Fisherbrand accumet pH/ATC epoxy-body double junction gel-filled electrode (Cat. No. 13-620-111)
- pH buffers, typically pH 4.01 buffer, pH 7.00 buffer, and pH 10.01 buffer
- Electrode storage solution
- Deionized water
- 50 mL beakers

pH/ATC Gel-Filled Electrode Setup

- 1. Remove any protective shipping materials from the pH electrode
- 2. Rinse the pH electrode with deionized water to remove any salt deposits
- Soak the pH electrode in electrode storage solution for at least 30 minutes prior to use; the sensing bulb and reference junction must be immersed in the electrode storage solution





Meter Preparation

- 1. Connect the assembled power adapter to the meter and wall outlet
- 2. Connect the pH/ATC electrode to the meter
- 3. Select the appropriate meter settings in the meter Setup Menu:
 - a. In the Measure Mode, press the Menu key to access the meter Setup Menu
 - b. The first Setup Menu item (View Logs, Data Log) will appear; to scroll through the Setup Menu list, use the ◄ and ► keys
 - Press the ► key to scroll to the next item
 - ii. Press the ◄ key to scroll to the previous item
 - iii. The list is cyclical, so continue to press the ► key to scroll from the last item to the first item again
 - c. To change a setting within a Setup Menu item, press the
 ▲ or ▼ key

For numeric value changes:

- Press the ▲ key once to increase the value by one least significant digit/unit
- Press the ▼ key once to decrease the value by one least significant digit/unit
- iii. Press and hold the ▲ key to quickly increase the value
- iv. Press and hold the ▼ key to quickly decrease the value
- d. Once a setting is changed, press the **Enter** key to save the change
- e. When viewing data logs or calibration logs, press the **Menu** key to go back to the main Setup Menu list
- f. Press the **Read** key at any time to exit the Setup Menu and return to the main measure mode

Setup Menu	Description	Default Screen/Setting
View Logs	View up to 500 data log points and active pH, RmV, and temperature calibrations.	E Menu L C C C C L C C C C L C C C C L C C C C
Log Export Type	Set the log export type as computer or printer. If computer is selected, the logs are exported in CSV format. If printer is selected, the logs are exported in list format.	E Menu E C D m P Press Anto codard Press Anto codard Press Enter to accept
Export All Logs	Send all saved data logs and calibration logs to the selected export device.	E Menu ALL Press Cito accept Press Enter to accept
Temp. Calibration or Manual Temp. Input	When an ATC probe is connected, use the Temperature Calibration menu to perform a one-point temperature offset calibration, up to $\pm 5^{\circ}$ C.	© ≡ Menu Measure © □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
	When no ATC probe is connected, use the Manual Temperature Input menu to enter the sample temperature value, from –5°C to 105°C.	E Menu MAN Press Avis occimi Press Avis occimi
Measure Mode	Set the main measure mode to pH or relative mV (RmV).	≡ Menu mV PH PH PH PH PH PH PH PH PH PH
pH Resolution	Set the displayed pH resolution as 0.01 or 0.1 pH units.	E Menu HILE E E E DE I Press ~V to change Press Ave to change Press Enter to accept
Calibration Buffer Set	Set the pH buffer set as USA, NIST, DIN, or FSCI for automatic buffer recognition during pH calibrations. USA: 2.00, 4.01, 7.00, 10.01, 12.00 NIST: 1.68, 4.01, 6.87, 9.18, 12.46 DIN: 1.09, 3.06, 4.65, 6.79, 9.23, 12.75 FSCI: 1.00, 3.00, 6.00, 8.00, 10.00, 13.00	E Menu E ALIEFF E AL Pres O to scroll Pres - V to change Pres Enter to accept
Read Type	Set the Read Type as Continuous, Auto-Read, or Timed to define how measurements are performed and when measurements are saved and exported.	
Timed Interval	When Timed is set as the Read Type, set the time interval from 5 seconds to 60 minutes. This time interval is used to automatically save and export measurements.	Timed Timed

Setup Menu	Description	Default Screen/Setting
Calibration Due Alarm	Set the calibration due alarm interval from 0 hours (off) to 60 hours. An alarm is triggered if a calibration is not performed within the specified time interval.	ERL Ohr OFF PressAvito change Press Enter to accept
Temperature Units	Set the temperature units as °C (Celsius) or °F (Fahrenheit).	E Menu L C C C C Press Avit to change Press Enter to accept
Set Date Format	Set the date format as month-day-year (MM.DD.YYYY) or day-month-year (DD.MM.YYYY).	E Menu HERC Model Pres 4 bascoll Pres Any to change Pres Enter to accept
Set Date Value	Set the month, day and year values. The date format used for this Setup Menu item will match the setting in the Set Date Format item.	E Menu
Set Time Value	Set the time in AM/PM format.	E Menu Pm Pm Pm Pm Pm Pm Pm Pm Pm Pm
Audio Mode	Set the audible beep on or off. The audible beep is used when an alarm is triggered.	E Menu Si Ca Ca Ca Ca Ca Pres <> to scroll Pres <> to scroll Pres <> to scroll Pres <> to change Pres Enter to accept
Sleep Mode	Set the sleep mode on or off. When the meter sleep mode is on, the meter will enter sleep mode when no keys are pressed for 20 minutes. Once the meter is in sleep mode, press the Power key to resume using the meter.	E Menu Si L E F F DF F Pres < > to scroll Pres Fres Enter to accept
Clear Data	Erase all data logs or erase all calibration logs.	E Menu E L E F F F F F F F F F F F F F F F F F
Factory Reset	Erase all data logs, calibration logs, and settings and return the meter to its factory default state.	E Menu F E E E E E E NO Press Av to change Press Enter to accept

Calibration Preparation

For best results, periodic calibration with known, accurate, and fresh pH buffers is recommended. During the pH calibration, the meter will automatically recognize each pH buffer value using the pH buffer set selected in the setup menu and the mV signal measured by the pH electrode. Once the reading is stable, the meter will automatically display the buffer value at its measured temperature from the selected buffer set.

1. Add about 30 mL of the pH 4.01 buffer to a 50 mL beaker and label the beaker.

2. Add about 30 mL of the pH 7.00 buffer to a 50 mL beaker and label the beaker.

3. Add about 30 mL of the pH 10.01 buffer to a 50 mL beaker and label the beaker.

Calibration Procedure

The following is an example of a three-point pH calibration using auto-recognized pH 4.01, 7.00 and 10.01 pH buffers. The pH buffers can be read in any order. For this example, pH buffers are read lowest to highest.



Sample Preparation

- 1. Add about 30 mL of the sample to a 50 mL beaker and label the beaker.
- 2. Repeat step 1 for additional samples.

Sample Measurement Procedure

- 1. Once the calibration is complete, prepare the samples to be measured.
- 2. Rinse the pH/ATC electrode and place into the first sample solution.
- 3. Wait for the pH value to stabilize. While the reading is stabilizing, the stopwatch icon is shown and the reading flashes. When the reading is stable, the checkmark icon is shown, and the reading is solid.
- 4. Once the reading is stable, record the sample pH and temperature values.
- 5. Remove the pH/ATC electrode from the sample.
- 6. Repeat steps 2 through 5 for all samples.
- 7. When all samples have been measured, store the equipment. Between samples and overnight, store the pH/ATC electrode in electrode storage solution.

Ordering Information

Description	Cat. No.
accumet AB315 pH/mV Bench Meter with Electrode Stand, Universal 110-240V Power Supply	13-636-AB315
accumet AB315 pH/mV Bench Meter Standard Kit with pH/ATC Epoxy-Body Double Junction Gel-Filled Electrode, Electrode Stand, Universal 110-240V Power Supply	13-636-AB315A
accumet pH/ATC Polymer-Body Double Junction Gel-Filled Electrode	13-620-111

Find out more at fishersci.com or fishersci.ca

This product is intended for General Laboratory Use. It is the customer's responsibility to ensure that the performance of the product is suitable for customers' specific use or application.

Distributed by Fisher Scientific. Contact us today:

In the United States Order online: fishersci.com Call customer service: 1-800-766-7000 In Canada Order online: fishersci.ca Call customer service: 1-800-234-7437

